

CT-MultiCom USB NW

Operating Card



MANUAL



 **CEOTRONICS**
when it counts

Getting Started

- Connect device (RSM) to End User Device (EUD) via Nett Warrior USB system on PAN port.
- RSM starts automatically. Red LED turns off when device is ready.
- Key appropriate PTT button to transmit.

Volume Control

- Press appropriate button "VOL +/-" to control the EUD system volume. The buttons are synchronized with the side buttons on the EUD.
- The button "MUTE" mutes the incoming audio.

Using Headsets

- Attach appropriate headset to corresponding jack.
- Headset is detected automatically:
 - Internal loudspeaker is muted.
 - Internal microphone is muted when an external microphone is detected.



The headset volume may exceed safe levels and must be appropriately limited by the user. Adjust the volume to the lowest acceptable level by using the volume controls.